

SCALABROS SRL

INSTRUCTION FOR THE SETTING OF MOTOR T ISTRUZIONE PER IL SETTAGGIO DEI MOTORI T

OPERATION	ITEM	ACTION	RESULT	ILLUSTRATION
Set the OPENING of a LEFT Roller Blind (for RIGHT Roller Blind, reverse the indicated directions of rotation)	1	Press the "down" button	The roller blind opens	
	2	If the roller blind does not run to the desired lower limit point, adjust the RED knob by turning it clockwise in the "+" direction	Until the roller blind runs to the desired lower limit point	
		If the roller blind opens more than you want, set the lower limit by turning the RED color knob counterclockwise in the "-" direction. The blind will not come back, but to check the result it is necessary to press the up button, in the opposite direction to make the roller blind go above the lower limit, and then repeat, if necessary, the operation setting, verifying the outcome from time to time. (note that this operation requires repeated operation)	After a repeated operation, until the roller blind reaches the desired lower limit	
3	After the lower limit is adjusted, press the stop button			
Set the CLOSING of a LEFT Roller Blind (for RIGHT Roller Blind, reverse the indicated directions of rotation)	4	Press the "up" button	The roller blind closes	
	5	If the roller blind does not run to the desired upper limit point, adjust the WHITE knob by turning it clockwise in the "+" direction	Until the roller blind runs to the desired upper limit point	
	If the roller blind closes more than you want, set the upper limit by turning the WHITE color knob counterclockwise in the "-" direction. The blind will not come back, but to check the result it is necessary to press the down button, in the opposite direction to make the roller blind go below the upper limit, and then repeat, if necessary, the operation setting, verifying the outcome from time to time. (note that this operation requires repeated operation)	After a repeated operation, until the roller blind reaches the desired upper limit		
6	After the upper limit is adjusted, press the stop button			

SCALABROS SRL

INSTRUCTION FOR THE SETTING OF MOTOR T ISTRUZIONE PER IL SETTAGGIO DEI MOTORI T

OPERAZIONE	ITEM	AZIONE	RISULTATO	ILLUSTRAZIONE
Impostare l'APERTURA di una Tenda SINISTRA (per tenda DESTRA invertire i sensi di rotazione indicati)	1	Premere il pulsante "giù"	La tenda si apre	
	2	<p>Se la tenda a rullo non raggiunge il limite inferiore desiderato, regolare la manopola di colore ROSSO ruotandola in senso orario nella direzione "+"</p> <p>Fino a quando la tenda a rullo non raggiunge il limite inferiore desiderato</p>	<p>Dopo un'operazione ripetuta, fino a quando la tenda a rullo non raggiunge il limite inferiore desiderato</p>	
		<p>Se la tenda a rullo si apre più di quanto si desidera, impostare il limite inferiore ruotando la manopola di colore ROSSO in senso antiorario nella direzione "-".</p> <p>La tenda non tornerà indietro, ma per verificarne l'esito è necessario premere il tasto su, nella direzione opposta per fare in modo che la tenda a rullo si metta al di sopra del limite inferiore, e quindi ripetere, se necessario, l'operazione di settaggio verificando di volta in volta l'esito. (notare che questa operazione richiede un'operazione ripetuta)</p>		
3	Dopo aver regolato il limite inferiore, premere il tasto di arresto			
Impostare la CHIUSURA di una Tenda SINISTRA (per tenda DESTRA invertire i sensi di rotazione indicati)	4	Premere il pulsante "su"	La tenda si chiude	
	5	<p>Se la tenda a rullo non raggiunge il limite superiore desiderato, regolare la manopola di colore BIANCO ruotandola in senso orario nella direzione "+"</p> <p>Fino a quando la tenda a rullo non raggiunge il limite superiore desiderato</p>	<p>Dopo un'operazione ripetuta, fino a quando la tenda a rullo non raggiunge il limite superiore desiderato</p>	
		<p>Se la tenda a rullo si chiude più di quanto si desidera, impostare il limite superiore ruotando la manopola di colore BIANCO in senso antiorario nella direzione "-".</p> <p>La tenda non tornerà indietro, ma per verificarne l'esito è necessario premere il tasto giù, nella direzione opposta per fare in modo che la tenda a rullo si metta al di sotto del limite superiore, e quindi ripetere, se necessario, l'operazione di settaggio verificando di volta in volta l'esito. (notare che questa operazione richiede un'operazione ripetuta)</p>		
6	Dopo aver regolato il limite superiore, premere il tasto di arresto			